



Please download the APP "Aibeile Plus"

s

4G Locator Quick Use Guide V1.0

Use the standard charging cable to charge the device

[Preparation before use](#)

- 1、 Please select a Nano-SIM phone card and turn it off before installing the card.
- 2、 The phone card of the device must be enabled with the call display function/4G Internet access function/ call function
- 3、 You can install a data card without calling if you only need the location function

Instruction of the device (The picture is for reference only, please refer to the material in kind!)



Power button: In shutdown state, press and hold for more than 5 seconds to power on; short press to turn off the screen, brighten the screen, hang up, return to the interface, etc.

SOS button: After setting the SOS number

successfully in the APP, hold down the SOS button for 3 seconds to dial the SOS number. After receiving the voice message, short press to return to the interface

Voice key: press twice to tell the time; When you receive a voice, press to listen.

When you receive an incoming call, press to answer the call

Purchase and install phone cards

Step 1: Choose a Nano-SIM phone card.

Please enable the call display function, 4G data traffic Internet access function, hd call function.

Step 2: Install the SIM card



Please turn off the device before inserting the card, as shown in the figure. With the metal side of the card facing up, align the card slot with the upper left corner of the card slot, and then insert the card slot into the device

Note: Do not remove the SIM card in the power-on state directly to prevent the card from being burnt; cutting the card may cause the card to not be inserted normally and damage the card slot.

About power on and off

Power on:

Press and hold the power button for 5 seconds to enable the power-on function

Power off:

(1) Without SIM card,
Long press the power button to automatically shut down.

(2) With SIM card:
Go to APP more - Settings - Remote Shutdown.

SOS button: press the button for 3 seconds after the card is turned on to trigger the SOS alarm.

※ If the device cannot be turned on normally or automatically shut down, please check whether the device is out of power. If there is no power, please charge it in time, and charge it for more than 10 minutes before turning it on.

Mobile APP download and login

Step 1: Download the APP

1, Search "AIBEILE" in the APP store to download, or scan the QR code to download



the APP

Step 2: Log in to the APP

After installing the card, observe whether the status bar of the device shows: signal grid, 4G, networking arrow, HD (there is no HD word on the iot card). If there are any, you can log in the APP to operate the device functions

Start the mobile app, select "Device Login" in the lower left corner, and enter your ID and password to log in.

2, After the device is added successfully, the mobile phone number and SOS number to be contacted can be saved in the APP Settings in advance (the short number must also be saved if the short number is opened), and other functions can be operated on the APP.

Note: Manage the device through APP. All operations on the device need to be pushed to the device through network. Limited by

**network conditions, there will be delay
sometimes, please do not worry**

Common functions

Telephone

If HD is not displayed in the drop-down list of the calling device, enable the device and restart it.

China Mobile: send SMS: Ktvolve to 10086 open

China Unicom: send SMS: DGvolve to 10010 open

China Telecom: send SMS: Ktvolve to 10001 open

Answer the call: When receiving a call, tap the voice key to answer.

Hang up: Press the power button to hang up

SOS for help: Press the power button for 3 seconds, the device will trigger the SOS alarm and automatically dial the SOS number to the guardian

voice chat

Device sends a voice: Press the voice button for 3 seconds and start recording (hold on). Release the voice and send it to the mobile APP. (The length of time the APP receives the voice is related to the network condition)

APP send voice: After entering the APP voice-chat, press and hold to speak, release the hand and send a voice message to the device. The maximum recording duration is 15 seconds. When the device receives

a voice message,click the voice key to play the voice

Other functions: historical track, electronic fence, step counting, refuse to receive calls from strangers, do not disturb mode, situational mode, health alert, SMS alert and other functions can be operated according to APP functional prompts.

Device charging

Please use 5V1A with CCC certification mark to charge, 5V 1A MAX, do not use the output voltage is higher than 5V, output current is higher than 2A quick charger, which may cause equipment damage!

- Before charging, please wipe the sweat at the charging thimble to prevent the salt in the sweat from electrolyzing the gold-plated layer, which may lead to the failure of charging.

- Charging time is recommended not to exceed 4 hours.

Please use the standard charging cable of the charger to charge the device, and make sure that the charging cable is aligned with the charging interface until the charging icon or "Charging..." appears on the screen of the device. ", start charging (if the charging interface is dirty, please clean it first).

Troubleshooting

*The device cannot be connected to the server when it is powered on for the first time. The APP sends instructions indicating that the device is not connected to the Internet or enabled, etc. Please check:

(1) First confirm whether the SIM card is normal, and be able to talk, surf the Internet and send text messages.

(2) Shutdown state after inserting the card and turning it on, pull down the status bar on the main interface to check SIM card signal grid, 4G, networking arrow, HD, etc. (Note: There is no HD word on the IOT card)

Edit SMS **pw,123456,ts#**(English keyboard) to the SIM card inserted into the device. The device card will reply the text message content, the common format is as follows:

ver:C405_GM _04R3_V1.6_2 021.10.23_10.. ID:951744905 5;	Version number and ID
imei:86399517 4490554;	Check that the IMEI is the same as that on the box

ip_url:a6*.com; port:7*5;	Check whether the DEVICE IP address starts with A6 and ends with COM.
profile:1; upload:600S; bat level:24; language:1; zone:8.00;	Position upload interval electricity The Chinese language East eight area
NET:OK(100);	Check if OK, signal bar >60

If you find any abnormality in the above items,
please contact customer service

Product hardware fault table

name	Performance failure
Equipment main body	Screen functional failure
	2 buttons physical performance failure
	Speakers are silent
Special note: When the product cannot be turned on or no display is displayed after charging, please hold down the power button for 20 seconds to reset (after the reset, it needs to be charged for more than 10 minutes before restarting), which is the protection function of the device and	

belongs to the normal phenomenon!

Personal Safety Information

Please install and use this product correctly. In order to ensure the safety of product use, please ensure that your product is not bound by unauthorized persons. Company promises, according to the National People's Congress standing committee "decision on strengthening the network information protection" of the standing committee of the National People's Congress on maintaining Internet security decision "and the" Internet electronic bulletin service management regulations "and other laws and regulations, technology and management measures to ensure the safety of network information, in accordance with the law to protect users' personal information, to ensure the security of your personal information. The company is not responsible for any illegal use of this product.

Declaration

- Welcome to use this equipment. The device consists of hardware and smart phone client software, which need to be used together

to achieve the functions of the device. Please read the operation instructions and safety information in this manual before making hardware to ensure safety and correct use. For details about the smart phone client software, see the software introduction.

- If you remove or change the shell of the product without permission, the product will lose the warranty qualification.

- Use the accessories provided by the original manufacturer to avoid unexpected damage. If you do not follow the correct procedures to use this product or connect incompatible accessories, such action will automatically void the warranty and may even endanger your safety and the safety of others. We assume no responsibility for this.

- Whether the function of this product can be realized depends on GSM(GPRS),LTE network system, GIS (geographic information) system and electronic computer system. This product needs to install the mobile phone card, and open the Internet function. The product can function normally only when the network is unobstructed. The company shall not be liable for any loss caused by service interruption due to network failure or any other force majeure

reasons.

- In line with the principle of continuous improvement and continuous development, the Company reserves the right to modify and improve any product described in the document without prior notice.

- The content in this manual is provided as it is at the time the product is manufactured, and unless otherwise required by applicable law, no warranty of any kind, express or implied, is made as to the accuracy, reliability or content of the documentation.

- To the maximum extent permitted by law, in no event shall the Company or its suppliers be liable for any special, incidental, incidental or consequential damages, whatever the cause.

Announcements

(1) Do not soak the product in water or in salt water, detergent or other liquid chemicals;

(2) Please keep the product away from fire source, high temperature and extreme environment;

(3) Please remind children to avoid eating the product by mistake;

(4) The positioning and calling function of the product cannot work when the power is off or outside the service area;

(5) It is strictly forbidden to use the wrong type of battery replacement and installation, there will be the risk of explosion, must be disposed of waste batteries in accordance with the national environmental protection requirements;

(6) If consumers use power adapters for power supply, they should purchase power adapters certified by CCC and meeting the standard requirements of 5V1A.