

# 1080P Pen Camera



## User Manual

### 1. Power on & record video:

Press the button for 3 seconds until the indicator light on. The camera is already recording a video now. The blue light will flash a few times then go off.

### 2. Check working state:

Press the top button one time to check if your camera is recording. If the blue light flash 1 time and then go out, your camera is recording a video. If there is no response from the indicator light, your camera is powered off.

### 3. Power off & save video:

When recording a video, press the top button for 3 seconds until the red light flash 3 times and then go out. The camera is turned off now and the previous recording has been saved as a video.

### 4. Charge battery:

When connecting the camera pen to a power supply, the red light will be solid on. The red light will turn to blue light when the camera pen is fully charged.

## Time Settings:

Default time setting is not to show the timestamp.

You can set the timestamp following the steps below:

1. Connect the device (with card inside) to your computer via the USB cable.
2. In the card storage, open the "time.txt".
3. You will see a timestamp format inside (2021-05-01 00:00:00 N). Change the time as you need but keep in the same format.
4. Change the last letter into "Y" to make the timestamp shows. Or "N" to hide the timestamp.
5. Restart your device with the card inside to active the change.

## Features:

Video Resolution	1920 X 1080P
Video Fps	30fps
Battery Capacity	350mAh
Working Time	180 mins
Maximum Memory	128GB
Power Supply	5V 1A